

STEP 1 Connection

Connecting a television with AUDIO/VIDEO, S-VIDEO or COMPONENT VIDEO terminals and VCR

Connecting to the television using the 21-pin Scart leads (⇒ page 7)


— indicates included accessories.

— indicates accessories not included.

① — ④ are required connections. Connect in the numbered order.

BE SURE TO READ THE CAUTION FOR THE AC MAINS LEAD ON PAGE 2 BEFORE CONNECTION.

To household mains socket
(AC 220–240 V, 50 Hz)



■ Component video output

Component signal outputs the colour difference signals (P_B/P_R) and luminance signal (Y) separately in order to achieve high fidelity in reproducing colours. If the television is compatible with progressive output, a high quality picture can be output because this unit's component video output terminal outputs a progressive output signal (⇒ page 55).

For progressive output (⇒ page 14)